

# **PASSENGER TRAIN RUNNING TIMES**

## **Status sheet 3 (Issued August 2009)**

This table shows the current status of units in this manual.

This sheet must be used to check that your manual contains all of these units and that each unit is up to date.

When a new status sheet is forwarded to you, it is your responsibility to add, remove or replace any pages or units from this manual.

The current page will be as indicated in the 'Last Issued' column below.

**status sheet**  
passenger train running times

<b>Page</b>	<b>Reprint Number</b>	<b>Last issued</b>
1	13	August 2009



**Western locomotive hauled running times**

COLUMN	AREA	COMPOSITION
Column 1 Down/Up	Sydney – Lithgow - Sydney	1 x NR 850 tonnes
Column 2 Down/Up	Sydney – Lithgow - Sydney	2 x NR 1280 tonnes

**Down**

	1	2
Sydney	↻	↻
Illawarra Jun	4	4
Ashfield	5	5
Strathfield	3	3
Homebush	1	1
Flem CS Jun	2	2
Lidcombe	1	1
Auburn	1	1
Clyde	2	2
Granville	1	1
Parramatta	2	1
Westmead	1	1
Seven Hills	4	4
Blacktown	2	2
St Marys	7	7
Penrith	5	5
Emu Plains	2	2
Glenbrook	11	10
Valley Heights	13	10
Springwood	4	3
Lawson	26	22
Wentworth Falls	11	9
Katoomba	12	10
Mt Victoria	18	18
Newnes Junction	14	14
Lithgow CS Box	13a	13a
Lithgow	2	2a

a = To arrive. All other times are passing.

**Up**

	1	2
Lithgow	↻	↻
Lithgow CS Box	2	2
Newnes Jun	13	13
Mt Victoria	14	14
Katoomba	18a	18a
Wentworth Falls	9	9
Lawson	6	6
Springwood	17	17
Valley Heights	2	2
Glenbrook	10	10
Emu Plains	10	10
Penrith	2	2
St Marys	5	5
Blacktown	7	7
Seven Hills	2	2
Westmead	4	4
Parramatta	2	2
Granville	2	2
Clyde	1	1
Auburn	1	1
Lidcombe	1	1
Flem Cs Jun	2	2
Homebush	2	2
Strathfield	1	1
Ashfield	3	3
Illawarra Jun	5	5
Sydney	4a	4a

